


Front view

TABLE OF CONTENTS

	section-page
INTRODUCTION	
General Information	1-1
Measurements	1-2
Specifications	1-3
Device Ratings	1-4
INSTALLATION	
Mounting	2-1
Connections	2-1
INITIAL SETUP	
Control Overview	3-1
Settings Screens Navigation	3-2
Password Selection	3-3
Electrical System Type	3-4
Source to Monitor	3-5
PT and CT Ratios	3-6
Serial Communication Interfaces ...	3-7 - 8
Engine Run Time Counter	3-9
Clear Engine Run Time Counter	3-10
Clear Min Max Parameters	3-11
Clear Energies	3-12
CT(s) Installed Option	3-13
Language Selection	3-14
Backlight Time Selection	3-15
Contrast Selection	3-16
Clear Demand Option	3-17
Demand Interval Option	3-18
Set Real Time Clock	3-19 - 23
OPERATION	
Operation	4-1
Operation Screens Navigation	4-2
Sample Screens	4-3 - 5
Wiring Diagrams	Appendix 1
Installation Drawing	Appendix 2
INDEX	back page



Rear view

! DANGER

To avoid possible shock, burns, or death, deenergize all electrical sources before making any connections to the Digital Power Meter.

NOTICE

The protection provided by the equipment may be impaired if the Digital Power Meter is used in a manner not specified by ASCO Power Technologies.

General Information

The Catalog 5210 Digital Power Meter (DPM) collects real-time power system information from ASCO Power Control Systems and Automatic Transfer Switches (ASCO Series 300, 4000 Series, 7000 Series). The DPM provides measurement for voltage, current, active power, reactive power, apparent power, active energy, reactive energy, apparent energy, power factor, and frequency. The intended use of the DPM is in the standard metering applications.

The DPM has built in serial communication interfaces. ASCOBUS II and serial Modbus RTU protocols are available to communicate with ASCO Power Quest or other monitoring applications via the built-in RS485 port or through the use of ASCO Catalog 5150 Connectivity Module (Accessory 72E). The APAC interface is used for communication with ASCO Catalog 5140 Quad-Ethernet Module (Accessory 72EE).

The DPM includes a backlit graphic LCD display and membrane controls (keys). All monitoring and control functions can be done from the front of the unit for convenience and safety.

The DPM can accommodate the following three phase and single phase system types:

- Single phase – 2 wire system (1 \emptyset – 2W)
- Single phase – 3 wire system (1 \emptyset – 3W)
- Three phase – 3 wire Delta system (3 \emptyset – 3W)
- Three phase – 4 wire WYE system (3 \emptyset – 4W)

Monitored & Calculated Data

The following computed parameters are available both on the local display and through the serial interface:

- Line-to-neutral voltages (V_{AN} , V_{BN} , V_{CN})
- Line-to-neutral voltage average (V_{AVE})
- Line-to-line voltages (V_{AB} , V_{BC} , V_{CA})
- Line-to-line voltage average (V_{LAVE})
- Current on each phase (I_A , I_B , I_C)
- Current in the neutral conductor (I_N)
- Average current (I_{AVE})
- Active power, kW per phase and total (W_A , W_B , W_C , W_T)
- Reactive power, kVAR per phase and total (VAR_A , VAR_B , VAR_C , VAR_T)
- Apparent power, kVA per phase and total (VA_A , VA_B , VA_C , VA_T)
- kWhours importing, exporting and net (kWh_{IMP} , kWh_{EXP} , kWh_{NET})
- kVARhours leading, lagging and net ($kVARh_{LEAD}$, $kVARh_{LAG}$, $kVARh_{NET}$)
- kVAhours net ($kVAh_{NET}$)
- Power factor (PF)
- Signal frequency (Hz)
- Total harmonic distortion (THD)
- Maximum kW demand (hourly, daily, monthly, yearly, etc.) with real-time clock

Transfer Switch Position Input (optional)



Used when the Digital Power Meter is providing measurement on the load terminal of a transfer switch.

Cleaning

The exterior of the Digital Power Meter should be cleaned by wiping the front panel of the display unit with a soft cloth and cleaning agents that are not alcohol based, and are non-flammable, non-explosive. All other servicing should be performed by authorized factory personnel.

Measurement Conventions

The following diagrams show how the Digital Power Meter interprets and displays signed (+, -) values for power, power factor and energy parameters. Please note that the polarity of the Watts, VARs, Power Factor, energy import/export, and lag/lead readings can be reversed by reversing the polarity of the CTs connected to the DPM.



DEFINITIONS:

$\Phi = (\text{phase angle between voltage and current}) = \Phi_v - \Phi_i$

$\Phi_v = \text{phase angle of voltage signal}$

$\Phi_i = \text{phase angle of current signal}$

LAGGING $\Phi = (0 < \Phi < 90^\circ)$ for positive power flow. To illustrate this condition, assume $\Phi_v = 0$ and $(-90^\circ < \Phi_i < 0)$. This results in $(0 < \Phi < 90^\circ)$, so it would be stated that Φ_i LAGS Φ_v for positive power flow.

LEADING $\Phi = (-90^\circ < \Phi < 0)$ for positive power flow. To illustrate this condition, assume $\Phi_v = 0$ and $(0 < \Phi_i < 90^\circ)$. This results in $(-90^\circ < \Phi < 0)$, so it would be stated that Φ_i LEADS Φ_v for positive power flow.

Measurement Specifications

- Temperature: 25 °C / 77°F
- Frequency : 50.0 Hz or 60.0 Hz
- Current input : $2\% < I_{FULL\ SCALE} < 125\%$
- Sensing type: True RMS up to and including the 31st harmonic.

Parameter (full scale)		Accuracy (% full scale)	Display	
			Resolution	Range
Current (I)	5.000 A	0.25 %	0.25 %	0-55 000 ¹
Voltage (V)	120 V	1.00 %	1.00 %	0-59 999 ²
	600 V	0.25 %	0.25 %	0-59 999 ²
Active Power (kW) (per element)	3000 W	0.25 %	0.10 %	0-99 999 ³
Reactive Power (kVAR) (per element)	3000 VAR	0.25 %	0.10 %	0-99 999 ³
Apparent Power (kVA) (per element)	3000 VA	0.25 %	0.10 %	0-99 999 ³
Active Energy (kWh)		1.00% of reading	0.10 %	- 1,999,999,999 to +1,999,999,999
Reactive Energy (kVARh)		1.00% of reading	0.10 %	- 1,999,999,999 to +1,999,999,999
Apparent Energy (kVAh)		1.00% of reading	0.10 %	- 1,999,999,999 to +1,999,999,999
Power Factor (PF)		1.00 %	0.01 PF	-0.0 to 1.00 to+0,0
Frequency (Hz)		0.25 %	0.1 Hz	40 to 100 Hz
Power (kW)		1.00% of reading	1 kW	1 to 32000
Maximum Power Demand (kW)		1.00% of reading	last 15 min	15 min to 13 months
			hourly	
			daily	
			monthly	
			last 30 days	
			last 13 months	

NOTES:

¹ Reads in kA (i.e., 10.00 kA) for currents over 9,999 A.

² Reads in kV (i.e., 10.0 kV) for voltages over 9,999 V.

³ Reads in MW, MVAR, MVA for readings over 9,999 k.

FCC Class A Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Device Ratings

Input Signals

Current (4):	0 to 5 A ac nominal. 4000 V ac isolation, minimum Burden: Less than 0.25VA per phase.
Voltage (3):	70 to 600 V ac nominal, phase to phase.
Frequency:	45 Hz to 65 Hz fundamental. True RMS measurements up to and including the 31st harmonic.
Transfer Switch Position input:	26 V dc maximum, >10 V dc = active, <1 V dc = inactive
AC Power Requirements:	minimum 70V L-L AC/103 mA / 7.2 VA with 50/60 Hertz
DC Power Requirements:	Optional backup power supply 9-36 V dc 10 watts DC power supply should be UL Listed.
Interface (s):	Isolated TTL Interface (J2) – DB9-female connector Isolated RS485 (J1) – 5 pin connector APAC interface (J4 & J5) – RJ12 connector
Operating Temp.:	-4 ° F to 158 ° F (-20° C to 70° C)
Storage Temp.:	-22 °F to 176 ° F (-30° C to 80° C)
Measurement Category:	III
Pollution Degree:	PD 2
Humidity:	Relative humidity 5% to 85%, non–condensing.

Applicable Standards

UL 61010-1 Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use
– Part 1: General Requirements

CSA-C22.2 No. 61010-1, 2nd Edition, 2004-07, Electrical Equipment for Measurement, Control, and
Laboratory Use; Part 1: General Requirements



To avoid possible shock, burns, or death, deenergize all electrical sources before making any connections to the Digital Power Meter.

Lethal voltages can result if current transformers are open circuited while carrying primary current. To avoid injury turn off primary circuit or short out CT secondary circuit.

NOTICE


To prevent damaging the Digital Power Meter deenergize all power to the unit before you connect or disconnect all wiring to the terminal blocks.

INSTALLATION

Mounting

The Power Meter must be mounted to a flat surface inside a metal enclosure. Mount the Digital Power Meter to the inside of an enclosure door which has a 10" x 6" cut out so that the LCD display and membrane controls are accessible through the door (when closed).

See Appendix 2 for mounting drawing.



Back of Power Meter

Connections

See Appendix 1 for connection diagrams. Make the appropriate connections as shown on the label on the Power Meter and on the wiring diagrams.

NOTICE

To prevent damaging the Digital Power Meter deenergize (turn off) all power to the unit before you connect or disconnect all wiring to the terminal blocks.

Tightening Torque

Tighten all Terminal Block connection terminals to 15 in-lb maximum.

Power Supply Connections (TB1 and J6) See *NOTICE* above.

AC Power Supply (TB1) - Connect the Phases A, B, C, and Neutral (if present) to terminal block TB1 as marked on the Power Meter. Refer to the labelling below the terminal block. Minimum AC input is 70V L-L AC and maximum AC input is 600V L-L AC with 50/60 Hertz frequency.

DC Power Supply (J6) – This is an optional but recommended backup dc power connection. If there is an AC power interruption, a DC power supply will allow communication with the Power Meter. Use a Class 1 power supply that is UL Listed. Connect the 0.3 amp. 24 volt dc power supply to terminal J6.1 (+) and terminal J6.2 (com) on Connector J6 marked on the Power Meter. Refer to the labelling below terminal block. The terminals accept 12-20 AWG stranded copper wire.



DANGER

To avoid possible shock, burns, or death, deenergize all electrical sources before making any connections to the Digital Power Meter.

Lethal voltages can result if current transformers are open circuited while carrying primary current. To avoid injury turn off primary circuit or short out CT secondary circuit.

CT Connections (TB2) See *DANGER* above!

Connect the current transformers (CTs) with 5 amp rated secondary to the appropriate terminals marked Current Inputs on the Power Meter. Refer to the labelling above terminal block TB2. Note the shorting block requirements on the Wiring Diagram. The high side (X1 or dot) terminals are marked **0**.

Voltage Connections (TB1) See *DANGER* above!

As described in the **AC Power Supply** section above, connect the system voltage (120 to 600 volts ac with 50/60 Hertz) to the appropriate terminals marked Voltage Inputs on the Power Meter. For system voltages above 600 volts ac use appropriate potential transformers (PTs). Refer to the labelling above terminal block TB3. Note the fusing requirements on the Wiring Diagram. (These input connections are same as the AC Power Supply Connections).

Transfer Switch Position (J3)

This connection is used if the Digital Power Meter is connected to a transfer switch's load terminals that is closed when the transfer switch is connected to the Normal source. If used, connect an unused transfer switch auxiliary contact (Feature 14A) to the appropriate terminals marked N/E Input on the DPM J3 terminals 1 & 2. Refer to the ATS Operator's Manual and ATS wiring diagram for the location of Feature 14A contact. This connection to the DPM allows it to monitor and display the position of the transfer switch. It also allows the DPM to properly attribute Watts, VA, VARs, PF, and min./max. values to either the Normal or Emergency source. The *Source to Monitor* setting (page 3-4) must be set to *Load*.

Ground Connection

The Power Meter is provided with a ground screw and ground wire with ring terminal (back lower left). Connect this ground wire to the inside grounded mounting stud.

When the Power Meter is mounted on an enclosure door, install a conductive strap between the enclosure and the door. This connection provides proper grounding which does not rely upon the door hinges.


Communication Network Connections

RS-485 Port (J1) - RS-485 Port is used to interface with Monitoring Systems or for networking with other Meters. J1 is used to connect the Power Meter directly to an RS-485 based communications network. Baud rates of 9600, 19200, 38400 and 57600 bps are supported on this interface.

Accessory 72E (J2) - Port Supports ASCObus II and serial Modbus protocols. A DB 9 female connector provides 24VDC power (max 100mA) to 5150 Connectivity Module (Acc. 72E).

The Connectivity Module (Acc. 72E) provides Ethernet access that allows user to view data from ASCO automatic transfer switches, Power Managers, and Digital Power Meters.

First, use ASCO cable 489672 (8 inch) or 489672-001 (4 foot) to connect the unit's serial communications interface connector J2 to the Acc. 72E Connectivity Module connector J2. Then, use only the recommended communication cable (see below) to connect the Acc. 72E Module to the RS-485 network. Connect the transmit and receive communication cable (twisted pairs) as shown on wiring diagrams in Appendix 1.




Acceptable Communication Cable


Type of Cable	Acceptable Manufacturer's Numbers
Standard 80° C	Belden 9842, 9829, Alpha 6202C, 6222C
Plenum Rated	Belden 89729, 82729, Alpha 58902


Accessory 72EE (J4, J5) - Ports support the APAC interface for the Group G controller used on new Series 300 3ATS, 3ADTS, 3NTS, 3NDTS transfer switches.


Control Overview


Six control buttons perform all monitoring and setting functions. Two levels of screens are used. The top level is the monitoring level and provides information about the power system. The lower level is the settings level. It may be necessary to enter a password to change a setting (see next page).



 **Left-Right arrow key** The left and right arrow keys navigate through both levels of screens.

 **Enter key** The enter key drops from the top level to the lower level settings screens. It also saves a new setting.

 **Up-Down arrow keys** The up and down arrow keys modify a setting (setup parameter) while in the lower level screens.

 **Escape key** The escape key ignores a change and returns to the top level.


Initial Setup

After installing the Digital Power Meter you must set these parameters:

- Password (required to change any setting)
- Type of electric system (3Ø-4W, 3Ø-3W, 1Ø-2W, 1Ø-3W)
- Source to be monitored (normal, emergency, load, other)
- Potential transformer (PT) and current transformer (CT) ratios
- Communication Port Settings
- Engine runtime(Enable or Disable)
- ATS Position (ON or OFF)
- Clear Run-time Engine Counter
- Clear Min max parameters
- Clear Energies
- CT Installed option (A, B, C or A-B-C)

If the Digital Power Meter is preinstalled as an ATS accessory, initial setup has already been done. You should set your password and clear the energy settings, however. Then go to Operation on page 4-1.

















Settings Screens Navigation




Password Selection NOTE: The initial password from the factory is **0000** which is the disabled password state.

The password can be alphanumeric. Select a four digit or letter password and record it here _ _ _ _

If incorrect password is entered you will see Invalid Password. Change the password as follows:







Step	Press	Display Shows	Comment
1			Displays the overview screen, if not already shown.
2			The Settings screen is displayed
3			Parameters under the General menu are shown
4			Press the up and down arrow keys until the Password option is highlighted.
5			Enter the old password to set a new password. The <u>first</u> digit is blinking
6			Press the up and down arrow keys until the correct <u>first</u> digit is displayed.
7			Press the right arrow key. Repeat steps 6 and 7 for the 2nd, 3rd, and 4 th digits
8			In the same way (steps 6 and 7), enter the new password, then press the enter key to save it.


Now press the  escape key to return to the top level display.

System Type

Select the type of electrical system that the Digital Power Meter is connected to.

- 3Ø-4 Wire (WYE)
- 3Ø-3 Wire (Delta)
- 1Ø-3 Wire
- 1Ø-2 Wire

Step	Press	Display Shows	Comment										
1		<table border="1"> <tr> <td>240V</td> <td>5A</td> </tr> <tr> <td>3.601kW</td> <td>+ 1.0PF</td> </tr> <tr> <td>0.000kW</td> <td>50.0Hz</td> </tr> <tr> <td>3.600kVA</td> <td>0.0Hrs</td> </tr> </table>	240V	5A	3.601kW	+ 1.0PF	0.000kW	50.0Hz	3.600kVA	0.0Hrs	Displays the overview screen if not already shown.		
240V	5A												
3.601kW	+ 1.0PF												
0.000kW	50.0Hz												
3.600kVA	0.0Hrs												
2		<table border="1"> <tr> <td colspan="2">SETTINGS</td> </tr> <tr> <td>General</td> <td>┆</td> </tr> <tr> <td>Communication</td> <td>┆</td> </tr> <tr> <td>Display</td> <td>┆</td> </tr> <tr> <td>Service</td> <td>┆</td> </tr> </table>	SETTINGS		General	┆	Communication	┆	Display	┆	Service	┆	The Settings screen is displayed.
SETTINGS													
General	┆												
Communication	┆												
Display	┆												
Service	┆												
3		<table border="1"> <tr> <td colspan="2">GENERAL</td> </tr> <tr> <td>System Type:</td> <td>3Ø-4W</td> </tr> <tr> <td>PT Ratio:</td> <td>120:120</td> </tr> <tr> <td>CT Ratio:</td> <td>5:5</td> </tr> <tr> <td>CT-N Ratio:</td> <td>5:5</td> </tr> </table>	GENERAL		System Type:	3Ø-4W	PT Ratio:	120:120	CT Ratio:	5:5	CT-N Ratio:	5:5	Parameters under the General menu are shown.
GENERAL													
System Type:	3Ø-4W												
PT Ratio:	120:120												
CT Ratio:	5:5												
CT-N Ratio:	5:5												
4		<table border="1"> <tr> <td colspan="2">GENERAL</td> </tr> <tr> <td>System Type:</td> <td>3Ø-4W</td> </tr> <tr> <td>PT Ratio:</td> <td>120:120</td> </tr> <tr> <td>CT Ratio:</td> <td>5:5</td> </tr> <tr> <td>CT-N Ratio:</td> <td>5:5</td> </tr> </table>	GENERAL		System Type:	3Ø-4W	PT Ratio:	120:120	CT Ratio:	5:5	CT-N Ratio:	5:5	System Type is blinking.
GENERAL													
System Type:	3Ø-4W												
PT Ratio:	120:120												
CT Ratio:	5:5												
CT-N Ratio:	5:5												
5		<table border="1"> <tr> <td colspan="2">GENERAL</td> </tr> <tr> <td>System Type:</td> <td>1Ø-2W</td> </tr> <tr> <td>PT Ratio:</td> <td>120:120</td> </tr> <tr> <td>CT Ratio:</td> <td>5:5</td> </tr> <tr> <td>CT-N Ratio:</td> <td>5:5</td> </tr> </table>	GENERAL		System Type:	1Ø-2W	PT Ratio:	120:120	CT Ratio:	5:5	CT-N Ratio:	5:5	Press the up and down arrow keys and select the desired System Type .
GENERAL													
System Type:	1Ø-2W												
PT Ratio:	120:120												
CT Ratio:	5:5												
CT-N Ratio:	5:5												
6		<table border="1"> <tr> <td colspan="2">GENERAL</td> </tr> <tr> <td>System Type:</td> <td>1Ø-2W</td> </tr> <tr> <td>PT Ratio:</td> <td>120:120</td> </tr> <tr> <td>CT Ratio:</td> <td>5:5</td> </tr> <tr> <td>CT-N Ratio:</td> <td>5:5</td> </tr> </table>	GENERAL		System Type:	1Ø-2W	PT Ratio:	120:120	CT Ratio:	5:5	CT-N Ratio:	5:5	Press the enter key to save the setting.
GENERAL													
System Type:	1Ø-2W												
PT Ratio:	120:120												
CT Ratio:	5:5												
CT-N Ratio:	5:5												















Now press the  escape key to return to the top level display.


Source to Monitor

Select the type of power source that the Digital Power Meter (DPM) is monitoring. This setting affects the manner in which Watts, VA, VARS, PF, and Min./Max. values are displayed by attributing them to the correct source.

- **Normal** typically used when DPM is connected to the Normal source terminals of a transfer switch.
- **Emergency** * typically used when DPM is connected to the Emergency source terminals of a transfer switch.
- **Load** * typically used when DPM is connected to the load terminals of a transfer switch (N or E sources).
To utilize this setting an auxiliary contact indicating that the transfer switch is connected to the Normal source (Feature 14A) must be connected to the Power Meter (page 2-2).
- **Other** typically used when DPM is providing monitoring of a non-specific source such as a distribution feeder. The effected values will be displayed without reference to a Normal or Emergency source.

* When set to **Emergency**, the Engine Run-Time display (page 4-3) may be enabled, page 3-8.

Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown.
2			The Settings screen is displayed.
3			Parameters under the General menu are shown.
4			Press the up and down arrow keys until the Source option is highlighted.
5			Source is blinking.
6			Press the up and down arrow keys and select the desired Source mode.
7			Press the enter key to save the setting.

Now press the  escape key to return to the top level display.

PT and CT Ratios

Select the ratios for the Potential Transformers (PTs) and Current Transformers (CTs) connected to the DPM as follows:

- **PT Ratios** based on system voltage, ratio is __:120, max. is 28200:120 (up to 600 V direct input use 120:120)
- **CT Ratios** based on ampere rating, ratio is __:5, adjustable from 5 to 55000 amperes in 5 ampere increments
- **CT-N Ratio** based on ampere rating, ratio is __:5, adjustable from 5 to 55000 or *OFF*.

The use of a current transformer on the neutral conductor is optional. Setting to *OFF* when not used will remove the CT-N value from the display when viewing the phase voltage and currents, page 4-2.

Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown.
2			The Settings screen is displayed.
3			Press the up and down arrow keys until the PT Ratio option is highlighted.
4			PT Ratio is blinking.
5			Press the up and down arrow keys and select the desired PT Ratio.
6			Press the enter key to save the setting.
7			Repeat steps 5 and 6 for the CT Ratio and CT-N Ratio .

Now press the escape key to return to the top level display.

Serial Communication Interface (SCI) port J2















If the Digital Power Meter is connected to a communications network via the SCI (J2) port, select the appropriate protocol, baud rate, and address for the port as follows:


Protocol

- **ASCOII** – Enters the Digital Power Meter in an ASCO emulation mode when used on ASCO ATs and *PowerQuest* devices.
- **Modbus RTU**– Choose this selection when the Digital Power Meter is to be used on a network that communicates via the Modbus RTU protocol. Contact ASCO Power Technologies to obtain a document detailing the corresponding Modbus protocol Register map definitions.

Baud Rate 9600 or 19200 bps

Address 1–239 (unique for each Digital Power Meter)

Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown.
2			The Settings screen is displayed. Press the up and down arrow keys until the Communication option is highlighted.
3			Press the up and down arrow keys until the SCI Protocol option is highlighted
4			SCI Protocol is blinking.
5			Press the up and down arrow keys and select the desired protocol.
6			Press the enter key to save the setting.
7			Repeat steps 5 and 6 for the SCI Address and SCI Baud Rate .

Now press the  escape key to return to the top level display.















RS485 Serial Communication Interface port J1


If the Digital Power Meter is connected to a communications network via the RS485 (J1) port, select the appropriate protocol, baud rate, and address for the port as follows:

Protocol

- **ASCOII** – Enters the Digital Power Meter in an ASCO I/O Module emulation mode when used on ASCO ATSS and *PowerQuest* devices.
- **Modbus RTU**– Choose this selection when the Digital Power Meter is to be used on a network that communicates via the Modbus RTU protocol. Contact ASCO Power Technologies to obtain a document detailing the corresponding Modbus protocol Register map definitions.

Baud Rate 9600, 19200, 38400, 57600 bps **Address** 1–239 (unique for each Digital Power Meter)

Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown.
2			The Settings screen is displayed. Press the up and down arrow keys until the Communication option is highlighted.
3			Press the up and down arrow keys until the 485 Protocol option is highlighted.
4			485 Protocol is blinking.
5			Press the up and down arrow keys and select the desired protocol.
6			Press the enter key to save the setting.
7			Repeat steps 5 and 6 for the 485 Address and 485 Baud Rate .

Now press the  escape key to return to the top level display.

Engine Runtime Counter

When the **Engine Runtime** setting is set to *ON* and the Emergency source is monitored, the *Engine Run-time* display, page 4-3, will provide totalized hours of engine operation. For the Engine Run-Time display to be operational the Digital Power Meter (DPM) must be used as follows:

- **DPM connected to the Emergency source terminals of a transfer switch**















Engine Runtime setting must be set to *ON*, Source to Monitor setting, page 3-4, must be set to *ON*

In this case the Runtime hours are totalized whenever at least 70 V L-L is present on the Voltage Inputs (TB1).

- **DPM connected to the Load terminals of a transfer switch**















Engine Runtime setting must be set to *ON*, Source to Monitor setting, page 3-4, must be set to *Load*.


The *ATS Position*, page 3-9, must be set to *ON* and an auxiliary contact from the transfer switch must be connected to the DPM, page 2-2.

Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown.
2			The Settings screen is displayed.
3			Parameters under the General menu are shown.
4			Press the up or down arrow keys until the Engine Run Time option is highlighted.
5			Engine Run Time is blinking.
6			Press the up or down arrow keys and select ON .
7			Press the enter key to save the setting.

Clear Engine Runtime Counter








The Engine Runtime Counter can be reset as follows


Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown.
2			The Settings screen is displayed.
3			Parameters under the General menu are shown.
4			Press the up and down arrow keys until the Clear Run Time option is highlighted.
5			Clear Run Time NO is blinking.
6			Press the up and down arrow keys and select YES .
7			The run time counter will be cleared and NO is shown again.

Now press the  escape key to return to the top level display.

Clear Min Max Parameters















The Digital Power Meter maintains a record of minimum and maximum of various parameters since the last CLEAR Operation. These records can be cleared as follows:


Step	Press	Display Shows	Comment
1		<pre> 240V 5A 3.601kW +1.0PF 0.000kW 50.0Hz 3.600kVA 0.0Hrs </pre>	Displays the overview screen if not already shown.
2		<pre> SETTINGS General J Communication J Display J Service J </pre>	The Settings screen is displayed.
3		<pre> GENERAL System Type: 3Ø-4W PT Ratio: 120:120 CT Ratio: 5:5 CT-N Ratio: 5:5 </pre>	Parameters under the General menu are shown.
4		<pre> GENERAL Engine Runtime: ON ATS Position: OFF Clear Run-time: NO Clear MinMax: NO </pre>	Press the up and down arrow keys until the Clear MinMax option is highlighted.
5		<pre> GENERAL Engine Runtime: ON ATS Position: OFF Clear Run-time: NO Clear MinMax: NO </pre>	Clear MinMax NO is blinking.
6		<pre> GENERAL Engine Runtime: ON ATS Position: OFF Clear Run-time: NO Clear MinMax: YES </pre>	Press the up and down arrow keys and select YES .
7		<pre> GENERAL Engine Runtime: ON ATS Position: OFF Clear Run-time: NO Clear MinMax: NO </pre>	The min max parameters will be cleared and NO is shown again

Now press the  escape key to return to the top level display.

Clear Energies

The energy registers include values for kWh (kilowatt hours) and kVARh (kiloVAR hours), both displayed as shown on page 4-2. These registers are updated on approximately one second intervals and stored into non-volatile (EEPROM) memory storage on 15 minute intervals. Clear the energy registers in non-volatile memory as follows:















Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown
2			The Settings screen is displayed
3			Parameters under the General menu are shown.
4			Press the up and down arrow keys until the Clear Energies option is highlighted.
5			Clear Energies NO is blinking.
6			Press the up and down arrow keys and select YES .
7			The Energies will be cleared and NO is shown again.


Now press the  escape key to return to the top level display.

CT(s) Installed Option

The *CT(s) Installed* setting is only displayed when the *System Type* setting, page 3-3, is set to 3Ø-3W or 3Ø-4W. This setting is required for the Digital Power Meter to correctly display measured and calculated electrical values by indicating which phases have current transformers installed.















Typical three phase systems have three current transformers (one per phase). Alternatively, a single current transformer may be installed on a user selected conductor when balanced loads are present on the three phase system being monitored. The CT(s) Installed setting must be set to indicate the phase(s) that current transformers are installed on as follows: *A-B-C* for typical three phase systems with unbalanced loads, or *A*, *B*, or *C* for three phase systems with balanced loads.


Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown.
2			The Settings screen is displayed.
3			Parameters under the General menu are shown.
4			Press the up and down arrow keys until the CT(s) Installed option is highlighted.
5			CT(s) Installed option is blinking.
6			Press the up and down arrow keys and select the desired option.
7			Press the enter key to save the setting.

Now press the  escape key to return to the top level display.

Language Selection









The Digital Power Meter supports English, Spanish, Italian, French, German, Portuguese, Russian, Korean, and Chinese languages for display of screens and Menu Navigation in its normal runtime. The required language can be selected by navigating to the Display Settings Menu.


Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown.
2			The Settings screen is displayed.
3			Press the up and down arrow keys until Display is highlighted.
4			Select the Language option.
5			Language option is blinking.
6			Press the up and down arrow keys and select the desired language option.
7			Press the enter key to save the setting.

Now press the  escape key to return to the top level display.

Backlight Time Selection

















The Backlighting setting determines the length of time the display backlight stays on when the Digital Power Meter is unattended (no key activity). Select OFF, ON (continuous), or 1 to 1999 minutes. Set Backlighting as follows:


Step	Press	Display Shows	Comment										
1		<table border="1"> <tr> <td>240V</td> <td>5A</td> </tr> <tr> <td>3.601kW</td> <td>+1.0PF</td> </tr> <tr> <td>0.000kW</td> <td>50.0Hz</td> </tr> <tr> <td>3.600kVA</td> <td>0.0Hrs</td> </tr> </table>	240V	5A	3.601kW	+1.0PF	0.000kW	50.0Hz	3.600kVA	0.0Hrs	Displays the Overview Screen if not already shown		
240V	5A												
3.601kW	+1.0PF												
0.000kW	50.0Hz												
3.600kVA	0.0Hrs												
2		<table border="1"> <tr> <td colspan="2">SETTINGS</td> </tr> <tr> <td>General</td> <td>┘</td> </tr> <tr> <td>Communication</td> <td>┘</td> </tr> <tr> <td>Display</td> <td>┘</td> </tr> <tr> <td>Service</td> <td>┘</td> </tr> </table>	SETTINGS		General	┘	Communication	┘	Display	┘	Service	┘	The Settings screen is displayed.
SETTINGS													
General	┘												
Communication	┘												
Display	┘												
Service	┘												
3		<table border="1"> <tr> <td colspan="2">SETTINGS</td> </tr> <tr> <td>General</td> <td>┘</td> </tr> <tr> <td>Communication</td> <td>┘</td> </tr> <tr> <td>Display</td> <td>┘</td> </tr> <tr> <td>Service</td> <td>┘</td> </tr> </table>	SETTINGS		General	┘	Communication	┘	Display	┘	Service	┘	Press the up and down arrow keys until Display is highlighted.
SETTINGS													
General	┘												
Communication	┘												
Display	┘												
Service	┘												
4		<table border="1"> <tr> <td colspan="2">DISPLAY</td> </tr> <tr> <td>Language</td> <td>ENGLISH</td> </tr> <tr> <td>Backlight</td> <td>1min</td> </tr> <tr> <td>Contrast</td> <td>50%</td> </tr> </table>	DISPLAY		Language	ENGLISH	Backlight	1min	Contrast	50%	Press the up and down arrow keys until Backlight is highlighted.		
DISPLAY													
Language	ENGLISH												
Backlight	1min												
Contrast	50%												
5		<table border="1"> <tr> <td colspan="2">DISPLAY</td> </tr> <tr> <td>Language</td> <td>ENGLISH</td> </tr> <tr> <td>Backlight</td> <td>1min</td> </tr> <tr> <td>Contrast</td> <td>50%</td> </tr> </table>	DISPLAY		Language	ENGLISH	Backlight	1min	Contrast	50%	Select the Backlight option.		
DISPLAY													
Language	ENGLISH												
Backlight	1min												
Contrast	50%												
6		<table border="1"> <tr> <td colspan="2">DISPLAY</td> </tr> <tr> <td>Language</td> <td>ENGLISH</td> </tr> <tr> <td>Backlight</td> <td>1min</td> </tr> <tr> <td>Contrast</td> <td>50%</td> </tr> </table>	DISPLAY		Language	ENGLISH	Backlight	1min	Contrast	50%	Backlight option is blinking.		
DISPLAY													
Language	ENGLISH												
Backlight	1min												
Contrast	50%												
7		<table border="1"> <tr> <td colspan="2">DISPLAY</td> </tr> <tr> <td>Language</td> <td>ENGLISH</td> </tr> <tr> <td>Backlight</td> <td>5min</td> </tr> <tr> <td>Contrast</td> <td>50%</td> </tr> </table>	DISPLAY		Language	ENGLISH	Backlight	5min	Contrast	50%	Press the up and down arrow keys and select the desired option.		
DISPLAY													
Language	ENGLISH												
Backlight	5min												
Contrast	50%												
8		<table border="1"> <tr> <td colspan="2">DISPLAY</td> </tr> <tr> <td>Language</td> <td>ENGLISH</td> </tr> <tr> <td>Backlight</td> <td>5min</td> </tr> <tr> <td>Contrast</td> <td>50%</td> </tr> </table>	DISPLAY		Language	ENGLISH	Backlight	5min	Contrast	50%	Press the enter key to save the setting.		
DISPLAY													
Language	ENGLISH												
Backlight	5min												
Contrast	50%												

Now press the  escape key to return to the top level display.

Contrast Selection








The Digital Power Meter allows configuration of Contrast percentage of the LCD Display. The Contrast can be set to a value between 0 and 100 in steps of 10. Contrast can be configured by navigating to the Display Settings Menu.


Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown.
2			The Settings screen is displayed.
3			Press the up and down arrow keys until Display is highlighted.
4			Press the up and down arrow keys until Contrast is highlighted.
5			Select the Contrast option.
6			Contrast option is blinking.
7			Press the up and down arrow keys and select the desired percentage.
8			Press the enter key to save the setting.

Now press the  escape key to return to the top level display.

Clear Demand Option








The Digital Power Meter has an option to clear the current instantaneous demand (instantaneous power) and maximum demand (YES/NO) for that particular month. This option can be set as follows:


Step	Press	Display Shows	Comment
1		<div style="border: 1px solid black; padding: 5px;"> <p>240V 5A 3.601kW +1.0PF 0.000kW 50.0Hz 3.600kVA 0.0Hrs</p> </div>	Displays the overview screen if not already shown.
2		<div style="border: 1px solid black; padding: 5px;"> <p>SETTINGS General J Communication J Display J Service J</p> </div>	The Settings screen is displayed.
3		<div style="border: 1px solid black; padding: 5px;"> <p>GENERAL System Type: 3Ø-4W PT Ratio: 120:120 CT Ratio: 5:5 CT-N Ratio: 5:5</p> </div>	Parameters under the General menu are shown.
4		<div style="border: 1px solid black; padding: 5px;"> <p>GENERAL Clear Energies: NO CT(s) Installed: A-B-C Clear Demand: NO Demand Intrl: 15</p> </div>	Press the up and down arrow keys until Clear Demand is highlighted.
5		<div style="border: 1px solid black; padding: 5px;"> <p>GENERAL Clear Energies: NO CT(s) Installed: A-B-C Clear Demand: NO Demand Intrl: 15</p> </div>	Clear Demand NO is blinking.
6		<div style="border: 1px solid black; padding: 5px;"> <p>GENERAL Clear Energies: NO CT(s) Installed: A-B-C Clear Demand: YES Demand Intrl: 15</p> </div>	Press the up and down arrow keys and select YES .
7		<div style="border: 1px solid black; padding: 5px;"> <p>GENERAL Clear Energies: NO CT(s) Installed: A-B-C Clear Demand: NO Demand Intrl: 15</p> </div>	Press the enter key. The Demand will be cleared and NO is shown again.

Now press the  escape key to return to the top level display.

Demand Interval Option

















The Digital Power Meter has an option to configure the Demand Integration period (1 to 15). This option can be set as follows:







Step	Press	Display Shows	Comment								
1		<div style="border: 1px solid black; padding: 5px;"> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">240V</td> <td style="width: 50%;">5A</td> </tr> <tr> <td>3.601kW</td> <td>+1.0PF</td> </tr> <tr> <td>0.000kW</td> <td>50.0Hz</td> </tr> <tr> <td>3.600kVA</td> <td>0.0Hrs</td> </tr> </table> </div>	240V	5A	3.601kW	+1.0PF	0.000kW	50.0Hz	3.600kVA	0.0Hrs	Displays the overview screen if not already shown.
240V	5A										
3.601kW	+1.0PF										
0.000kW	50.0Hz										
3.600kVA	0.0Hrs										
2		<div style="border: 1px solid black; padding: 5px;"> <p>SETTINGS</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 80%;">General</td> <td style="width: 20%; text-align: right;">J</td> </tr> <tr> <td>Communication</td> <td style="text-align: right;">J</td> </tr> <tr> <td>Display</td> <td style="text-align: right;">J</td> </tr> <tr> <td>Service</td> <td style="text-align: right;">J</td> </tr> </table> </div>	General	J	Communication	J	Display	J	Service	J	The Settings screen is displayed.
General	J										
Communication	J										
Display	J										
Service	J										
3		<div style="border: 1px solid black; padding: 5px;"> <p>GENERAL</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">System Type:</td> <td style="width: 30%; text-align: right;">3Ø-4W</td> </tr> <tr> <td>PT Ratio:</td> <td style="text-align: right;">120:120</td> </tr> <tr> <td>CT Ratio:</td> <td style="text-align: right;">5:5</td> </tr> <tr> <td>CT-N Ratio:</td> <td style="text-align: right;">5:5</td> </tr> </table> </div>	System Type:	3Ø-4W	PT Ratio:	120:120	CT Ratio:	5:5	CT-N Ratio:	5:5	Parameters under the General menu are shown.
System Type:	3Ø-4W										
PT Ratio:	120:120										
CT Ratio:	5:5										
CT-N Ratio:	5:5										
4		<div style="border: 1px solid black; padding: 5px;"> <p>GENERAL</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">Clear Energies:</td> <td style="width: 30%; text-align: right;">NO</td> </tr> <tr> <td>CT(s) Installed:</td> <td style="text-align: right;">A-B-C</td> </tr> <tr> <td>Clear Demand:</td> <td style="text-align: right;">NO</td> </tr> <tr> <td>Demand Intrl:</td> <td style="text-align: right;">15</td> </tr> </table> </div>	Clear Energies:	NO	CT(s) Installed:	A-B-C	Clear Demand:	NO	Demand Intrl:	15	Press the up and down arrow keys until Demand Intrl is highlighted.
Clear Energies:	NO										
CT(s) Installed:	A-B-C										
Clear Demand:	NO										
Demand Intrl:	15										
5		<div style="border: 1px solid black; padding: 5px;"> <p>GENERAL</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">Clear Energies:</td> <td style="width: 30%; text-align: right;">NO</td> </tr> <tr> <td>CT(s) Installed:</td> <td style="text-align: right;">A-B-C</td> </tr> <tr> <td>Clear Demand:</td> <td style="text-align: right;">NO</td> </tr> <tr> <td>Demand Intrl:</td> <td style="text-align: right;">15</td> </tr> </table> </div>	Clear Energies:	NO	CT(s) Installed:	A-B-C	Clear Demand:	NO	Demand Intrl:	15	Demand Intrl 15 is blinking.
Clear Energies:	NO										
CT(s) Installed:	A-B-C										
Clear Demand:	NO										
Demand Intrl:	15										
6		<div style="border: 1px solid black; padding: 5px;"> <p>GENERAL</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">Clear Energies:</td> <td style="width: 30%; text-align: right;">NO</td> </tr> <tr> <td>CT(s) Installed:</td> <td style="text-align: right;">A-B-C</td> </tr> <tr> <td>Clear Demand:</td> <td style="text-align: right;">NO</td> </tr> <tr> <td>Demand Intrl:</td> <td style="text-align: right;">10</td> </tr> </table> </div>	Clear Energies:	NO	CT(s) Installed:	A-B-C	Clear Demand:	NO	Demand Intrl:	10	Press the up and down arrow keys and select the desired interval.
Clear Energies:	NO										
CT(s) Installed:	A-B-C										
Clear Demand:	NO										
Demand Intrl:	10										
7		<div style="border: 1px solid black; padding: 5px;"> <p>GENERAL</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">Clear Energies:</td> <td style="width: 30%; text-align: right;">NO</td> </tr> <tr> <td>CT(s) Installed:</td> <td style="text-align: right;">A-B-C</td> </tr> <tr> <td>Clear Demand:</td> <td style="text-align: right;">NO</td> </tr> <tr> <td>Demand Intrl:</td> <td style="text-align: right;">10</td> </tr> </table> </div>	Clear Energies:	NO	CT(s) Installed:	A-B-C	Clear Demand:	NO	Demand Intrl:	10	Press the enter key to save the setting.
Clear Energies:	NO										
CT(s) Installed:	A-B-C										
Clear Demand:	NO										
Demand Intrl:	10										


Now press the  escape key to return to the top level display.

Time Option

The Digital Power Meter has an option to configure the real time clock time setting. This option can be set as follows:















Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown.
2			The Settings screen is displayed.
3			Parameters under the General menu are shown.
4			Press the up and down arrow keys until Time is highlighted.
5			HH (hours) is blinking.
6			Press the up and down arrow keys and select the current hour.
7			Press the right arrow key. MM (minutes) is blinking.
8			Press the up and down arrow keys and select the current minute.









9			Press the right arrow key. SS (seconds) is blinking.
10			Press the up and down arrow keys and select the current second.
11			Press the enter key to save the time setting.


Now press the  escape key to return to the top level display.

Date Option

The Digital Power Meter has an option to configure the real time clock date setting. This option can be set as follows:















Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown.
2			The Settings screen is displayed.
3			Parameters under the General menu are shown.
4			Press the up and down arrow keys until Date is highlighted.
<p>Date Format can be set for US (MM DD YY), EU (DD MM YY), or ISO (YY MM DD). The setting process is similar but in different month, day, year order. US format is shown here.</p>			
5			MM (month) is blinking.
6			Press the up and down arrow keys and select the current month.
7			Press the right arrow key. DD (day of the month) is blinking.


8			Press the up and down arrow keys and select the current day of the month.
9			Press the right arrow key. YY (year) is blinking.
10			Press the up and down arrow keys and select the current year (last two digits).
11			Press the enter key to save the date setting.

Now press the  escape key to return to the top level display.

Day of the Week Option

The Digital Power Meter has an option to configure the real time clock day of the week setting. This option can be set as follows:

Step	Press	Display Shows	Comment
1			Displays the overview screen if not already shown.
2			The Settings screen is displayed.
3			Parameters under the General menu are shown.
4			Press the up and down arrow keys until Day is highlighted.
5			The day of the week is blinking.
6			Press the up and down arrow keys and select the current day of the week.
11			Press the enter key to save the date of the week setting.

Now press the  escape key to return to the top level display.


Operation

From the top level display the Digital Power Meter can show the following information about the electrical power system:


- System totals (kW, kVAR, kVA, PF, Hz, position of ATS)
- Current and Voltage (line-to-neutral & line-to-line) – all phases
- Power (kW), kVARs, kVA, & PF (power factor) – all phases
- Average current & voltage (line-to-neutral & line-to-line)
- Unbalance % amps & voltage (line-to-neutral & line-to-line)
- Neutral current (if neutral is connected to Digital Power Meter)
- kW hours (imp, exp, net) for Normal & Emergency sources
- kVAR hours (lag, lead, net) for Normal & Emergency sources

Data is updated approximately every second.

As the default screen, the following screen shows the overview of the system




















Operation Screens Navigation








Following are the screens for a 3Ø, 4-Wire wye system and monitored source is Load. Engine Runtime Counter is assumed to be ON and ATS Position is assumed to be OFF. Screens may be different for other electrical systems or other monitored sources.

NOTE: The values of various parameters in the following screens are only for demonstrative purpose and do not reflect the actual calculations.


Step	Press	Display Shows	Comment																				
1		<table border="1"> <tr> <td>480V</td> <td>2000A</td> </tr> <tr> <td>2880kW</td> <td>+1.00PF</td> </tr> <tr> <td>0kVAr</td> <td>50.5Hz</td> </tr> <tr> <td>2880kVA</td> <td>0.0Hrs</td> </tr> </table>	480V	2000A	2880kW	+1.00PF	0kVAr	50.5Hz	2880kVA	0.0Hrs	Overview screen shows V, A, kW, PF, kVAR, kVA, Hz, generator hours, and ATS position.												
480V	2000A																						
2880kW	+1.00PF																						
0kVAr	50.5Hz																						
2880kVA	0.0Hrs																						
2		<table border="1"> <tr> <th>Ø</th> <th>V-LN</th> <th>V-LL</th> <th>AMPS</th> </tr> <tr> <td>A</td> <td>59.9k</td> <td>59.9k</td> <td>29.9k</td> </tr> <tr> <td>B</td> <td>59.9k</td> <td>59.9k</td> <td>29.9k</td> </tr> <tr> <td>C</td> <td>59.9k</td> <td>59.9k</td> <td>29.9k</td> </tr> <tr> <td>CT-N</td> <td></td> <td></td> <td>29.9k</td> </tr> </table>	Ø	V-LN	V-LL	AMPS	A	59.9k	59.9k	29.9k	B	59.9k	59.9k	29.9k	C	59.9k	59.9k	29.9k	CT-N			29.9k	Shows voltage (line to neutral, line to line) and current on all phases.
Ø	V-LN	V-LL	AMPS																				
A	59.9k	59.9k	29.9k																				
B	59.9k	59.9k	29.9k																				
C	59.9k	59.9k	29.9k																				
CT-N			29.9k																				
3		<table border="1"> <tr> <th>Ø</th> <th>WATTS</th> <th>PF</th> </tr> <tr> <td>A</td> <td>0.000k</td> <td>0.00</td> </tr> <tr> <td>B</td> <td>0.000k</td> <td>0.00</td> </tr> <tr> <td>C</td> <td>0.000k</td> <td>0.00</td> </tr> <tr> <td>Total</td> <td>0.000k</td> <td></td> </tr> </table>	Ø	WATTS	PF	A	0.000k	0.00	B	0.000k	0.00	C	0.000k	0.00	Total	0.000k		Shows active power (kW) and power factor (PF) on all phases and total.					
Ø	WATTS	PF																					
A	0.000k	0.00																					
B	0.000k	0.00																					
C	0.000k	0.00																					
Total	0.000k																						
4		<table border="1"> <tr> <th>Ø</th> <th>VAs</th> <th>VARs</th> </tr> <tr> <td>A</td> <td>0.000k</td> <td>0.000k</td> </tr> <tr> <td>B</td> <td>0.000k</td> <td>0.000k</td> </tr> <tr> <td>C</td> <td>0.000k</td> <td>0.000k</td> </tr> <tr> <td>Total</td> <td>0.000k</td> <td>0.000k</td> </tr> </table>	Ø	VAs	VARs	A	0.000k	0.000k	B	0.000k	0.000k	C	0.000k	0.000k	Total	0.000k	0.000k	Shows apparent (VA) and reactive power (VAR) on all phases and total.					
Ø	VAs	VARs																					
A	0.000k	0.000k																					
B	0.000k	0.000k																					
C	0.000k	0.000k																					
Total	0.000k	0.000k																					
5		<table border="1"> <tr> <th colspan="2">kWh - Normal</th> </tr> <tr> <td>IMPORT ></td> <td>0.000</td> </tr> <tr> <td>EXPORT ></td> <td>0.000</td> </tr> <tr> <td>NET ></td> <td>0.000</td> </tr> </table>	kWh - Normal		IMPORT >	0.000	EXPORT >	0.000	NET >	0.000	Shows the power usage (kWH) imported, exported, and total for the normal source.												
kWh - Normal																							
IMPORT >	0.000																						
EXPORT >	0.000																						
NET >	0.000																						
6		<table border="1"> <tr> <th colspan="2">kVarh - Normal</th> </tr> <tr> <td>LAG ></td> <td>0.000</td> </tr> <tr> <td>LEAD ></td> <td>0.000</td> </tr> <tr> <td>NET ></td> <td>0.000</td> </tr> <tr> <td>kVAh ></td> <td>0.000</td> </tr> </table>	kVarh - Normal		LAG >	0.000	LEAD >	0.000	NET >	0.000	kVAh >	0.000	Shows Reactive and Apparent Energy for the normal source										
kVarh - Normal																							
LAG >	0.000																						
LEAD >	0.000																						
NET >	0.000																						
kVAh >	0.000																						
7		<table border="1"> <tr> <th colspan="2">kWh - Emergency</th> </tr> <tr> <td>IMPORT ></td> <td>0.000</td> </tr> <tr> <td>EXPORT ></td> <td>0.000</td> </tr> <tr> <td>NET ></td> <td>0.000</td> </tr> </table>	kWh - Emergency		IMPORT >	0.000	EXPORT >	0.000	NET >	0.000	Shows the power usage (kWH) imported, exported, and total for the emergency source.												
kWh - Emergency																							
IMPORT >	0.000																						
EXPORT >	0.000																						
NET >	0.000																						
8		<table border="1"> <tr> <th colspan="2">kVarh - Emergency</th> </tr> <tr> <td>LAG ></td> <td>0.000</td> </tr> <tr> <td>LEAD ></td> <td>0.000</td> </tr> <tr> <td>NET ></td> <td>0.000</td> </tr> <tr> <td>kVAh ></td> <td>0.000</td> </tr> </table>	kVarh - Emergency		LAG >	0.000	LEAD >	0.000	NET >	0.000	kVAh >	0.000	Reactive and Apparent Energy for Emergency Source										
kVarh - Emergency																							
LAG >	0.000																						
LEAD >	0.000																						
NET >	0.000																						
kVAh >	0.000																						

9		<table border="1"> <thead> <tr> <th colspan="3">% Full Load</th> </tr> <tr> <th>Ø</th> <th>AMPs</th> <th>WATTS</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>0%</td> <td>0%</td> </tr> <tr> <td>B</td> <td>0%</td> <td>0%</td> </tr> <tr> <td>C</td> <td>0%</td> <td>0%</td> </tr> </tbody> </table>	% Full Load			Ø	AMPs	WATTS	A	0%	0%	B	0%	0%	C	0%	0%	% Full Load					
% Full Load																							
Ø	AMPs	WATTS																					
A	0%	0%																					
B	0%	0%																					
C	0%	0%																					
10		<table border="1"> <thead> <tr> <th></th> <th>AVG</th> <th>UNBAL</th> </tr> </thead> <tbody> <tr> <td>AMPs</td> <td>0.0</td> <td>0%</td> </tr> <tr> <td>V-LL</td> <td>0</td> <td>0%</td> </tr> <tr> <td>V-LN</td> <td>0</td> <td>0%</td> </tr> </tbody> </table>		AVG	UNBAL	AMPs	0.0	0%	V-LL	0	0%	V-LN	0	0%	Shows average current and voltage (line to line, line to neutral) and percent unbalanced.								
	AVG	UNBAL																					
AMPs	0.0	0%																					
V-LL	0	0%																					
V-LN	0	0%																					
11		<table border="1"> <thead> <tr> <th></th> <th>Normal</th> <th>Min.</th> <th>Max.</th> </tr> </thead> <tbody> <tr> <td>V-LL</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>AMPs</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Hz</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table>		Normal	Min.	Max.	V-LL	0	0	0	AMPs	0	0	0	Hz	0	0	0	Shows the minimum and maximum voltage, current, and frequency for the normal source.				
	Normal	Min.	Max.																				
V-LL	0	0	0																				
AMPs	0	0	0																				
Hz	0	0	0																				
12		<table border="1"> <thead> <tr> <th></th> <th>Normal</th> <th>Min.</th> <th>Max.</th> </tr> </thead> <tbody> <tr> <td>WATTS</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>VAs</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>VARs</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>PF</td> <td>0.00</td> <td>0.00</td> <td>0.00</td> </tr> </tbody> </table>		Normal	Min.	Max.	WATTS	0	0	0	VAs	0	0	0	VARs	0	0	0	PF	0.00	0.00	0.00	Shows the minimum and maximum kW, VA, VAR, and PF for the normal source.
	Normal	Min.	Max.																				
WATTS	0	0	0																				
VAs	0	0	0																				
VARs	0	0	0																				
PF	0.00	0.00	0.00																				
13		<table border="1"> <thead> <tr> <th></th> <th>Emerg.</th> <th>Min.</th> <th>Max.</th> </tr> </thead> <tbody> <tr> <td>V-LL</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>AMPs</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Hz</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table>		Emerg.	Min.	Max.	V-LL	0	0	0	AMPs	0	0	0	Hz	0	0	0	Shows the minimum and maximum voltage, current, and frequency for the emergency source.				
	Emerg.	Min.	Max.																				
V-LL	0	0	0																				
AMPs	0	0	0																				
Hz	0	0	0																				
14		<table border="1"> <thead> <tr> <th></th> <th>Emerg.</th> <th>Min.</th> <th>Max.</th> </tr> </thead> <tbody> <tr> <td>WATTS</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>VAs</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>VARs</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>PF</td> <td>0.00</td> <td>0.00</td> <td>0.00</td> </tr> </tbody> </table>		Emerg.	Min.	Max.	WATTS	0	0	0	VAs	0	0	0	VARs	0	0	0	PF	0.00	0.00	0.00	Shows the minimum and maximum kW, VA, VAR, and PF for the emergency source.
	Emerg.	Min.	Max.																				
WATTS	0	0	0																				
VAs	0	0	0																				
VARs	0	0	0																				
PF	0.00	0.00	0.00																				
15		<table border="1"> <thead> <tr> <th colspan="2">Max kW Summary</th> </tr> </thead> <tbody> <tr> <td>Last 60 Min</td> <td>0 kW</td> </tr> <tr> <td>Last 24 Hr</td> <td>0 kW</td> </tr> <tr> <td>Last 30 Day</td> <td>0 kW</td> </tr> <tr> <td>Last 12 Month</td> <td>0 kW</td> </tr> </tbody> </table>	Max kW Summary		Last 60 Min	0 kW	Last 24 Hr	0 kW	Last 30 Day	0 kW	Last 12 Month	0 kW	Shows the load demand in the past 60 min, 24 hours, 30 days, and 12 months.										
Max kW Summary																							
Last 60 Min	0 kW																						
Last 24 Hr	0 kW																						
Last 30 Day	0 kW																						
Last 12 Month	0 kW																						
16		<table border="1"> <thead> <tr> <th colspan="2">Max Demand Details</th> </tr> </thead> <tbody> <tr> <td>Last Interval (10Mins)</td> <td>0 kW</td> </tr> <tr> <td>Date @ time</td> <td>(Instantaneous)</td> </tr> </tbody> </table>	Max Demand Details		Last Interval (10Mins)	0 kW	Date @ time	(Instantaneous)	Shows more load demand details in past 10 minutes, 60 minutes, 24 hours, 30 days, and 12 months. Press the down arrow for the next interval.														
Max Demand Details																							
Last Interval (10Mins)	0 kW																						
Date @ time	(Instantaneous)																						
17		<table border="1"> <thead> <tr> <th></th> <th>2014</th> <th>2013</th> </tr> </thead> <tbody> <tr> <td>Jan</td> <td>0 kW</td> <td>0 kW</td> </tr> <tr> <td>Feb</td> <td>0 kW</td> <td>0 kW</td> </tr> <tr> <td>Mar</td> <td>0 kW</td> <td>0 kW</td> </tr> </tbody> </table>		2014	2013	Jan	0 kW	0 kW	Feb	0 kW	0 kW	Mar	0 kW	0 kW	Shows a comparison of monthly load demand this year versus last year. Press the down arrow for the next three months.								
	2014	2013																					
Jan	0 kW	0 kW																					
Feb	0 kW	0 kW																					
Mar	0 kW	0 kW																					

18		<p>Engine Run-time</p> <p>Resettable: 0.0Hrs Cumulative: 0.0Hrs</p>	Shows the total hours of operation for the generator (run time counters).
19		<p>CURRENT THD</p> <p>Ø % THD A >> 0.00 B >> 0.00 B >> 0.00</p>	Shows the Total Harmonic Distortion for each current per phase.
20		<p>VOLTAGE THD</p> <p>Ø % THD A >> 0.00 B >> 0.00 B >> 0.00</p>	Shows the Total Harmonic Distortion for each voltage per phase.
21		<p>Watt Demand</p> <p>INST: 0 kW MAX: 0 kW</p>	Shows the maximum watt demand over a configured interval. Inst: watt demand for most recent interval. Max: highest watt demand of any interval since last reset.
22		<p>POWER METER ASCO PowerTech, L.P. Copyright(C), 2008 www.ascopower.com</p>	Logo Screen

Press the right arrow again to return to the overview screen.

**2 Wire Single Phase
Input Voltage < 600 V ac (L-L), no external PTs**




Setting: 1Ø - 2 Wire
PT Ratio: 120:120
See notes 1, 2, 3.

Notes:


1. A shorting terminal block is required at the CT location.
2. Voltage inputs require 1 A 600 V slow-blow fuses.
3. Use UL rated 14 to 20 AWG copper wire for making the connection.
4. Fuses(s) should be installed on all "hot" voltage inputs.

**3 Wire Single Phase
Input Voltage < 600 V ac (L-L), no external PTs**



Setting: 1Ø - 3 Wire
PT Ratio: 120:120
See notes 1, 2, 3.

**3 Wire Delta System
Input Voltage < 600 V ac (L-L), no external PTs**




Setting: 3Ø – 3 Wire Delta
PT Ratio: 120:120
See notes 1, 2, 3, 4, 5.

Notes:


1. A shorting terminal block is required at the CT location.
2. Voltage inputs require 1 A 600 V slow-blow fuses.
3. Use UL rated 14 to 20 AWG copper wire for making the connection.
4. European convention for phase marking, UVW, shown in parenthesis next to A, B, C markings.
5. Use this wiring configuration for balanced loads only.

**3 Wire Delta System with required PTs
Input Voltage > 600 V ac (L-L), external PTs**



Setting: 3Ø – 3 Wire Delta
PT Ratio: Primary Rating :120
See notes 1, 2, 3, 4, 5.

4 Wire WYE System
Input Voltage < 600 V ac (L-L), no external PTs




Setting: 3Ø – 4 Wire WYE
 PT Ratio: 120:120
 See notes 1, 2, 3, 4.

Notes:

1. A shorting terminal block is required at the CT location.
2. Voltage inputs require 1 A 600 V slow-blow fuses.
3. Use UL rated 14 to 20 AWG copper wire for making the connection.
4. European convention for phase marking, UVW, shown in parenthesis next to A, B, C markings.


4 Wire WYE System with required PTs
Input Voltage > 600 V ac (L-L), external PTs



Setting: 3Ø – 4 Wire WYE
 PT Ratio: Primary Rating :120
 See notes 1, 2, 3, 4.

Ground Connection

4 Wire WYE System with 1 Phase Current Input Voltage < 600 V ac (L-L), no external PTs



Setting: 3Ø – 4 Wire WYE
 PT Ratio: 120:120
 See notes 1, 2, 3, 4.

Notes:

1. A shorting terminal block is required at the CT location.
2. Voltage inputs require 1 A 600 V slow-blow fuses.
3. Use UL rated 14 to 20 AWG copper wire for making the connection.
4. European convention for phase marking, UVW, shown in parenthesis next to A, B, C markings.

**RS485 4-Wire Mode
& ATS auxiliary contact connection**





Table 1


Switch	ON (A & B)	OFF (A & B)
S1	Termination added	Termination Removed
S2	2-wire mode	4-wire mode

A-ON & B-OFF status is not Recommended.
A-OFF & B-ON status is not Recommended.


TTL Interface with Connectivity Module & LED Indication Details




DC Power Supply & APAC Interface Details



-JP1 NOTE: For cases where the DPM stands alone and the DPM powers the Connectivity Module, JP1 jumper must be installed.



Serial Data Entry Connection Diagram






FIGURE #1

DIGITAL POWER METER INSTALLATION FOR TYPE 1, 3R, 4, & 12 ENCLOSURES

NOTES:

1. UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCH [mm].
2. MOUNT DIGITAL POWER METER TO ENCLOSURE AS INDICATED. IN FIGURE #1, OVERLAY THE BEZEL INTO THE CUTOUT. USING THE BEZEL AS A TEMPLATE, PUNCH THE 20 HOLES INTO THE MEMBRANE THAT CORRESPOND WITH THE HOLES IN THE BEZEL.
3. IF THE METER IS TO BE MOUNTED IN AN EXISTING ASCO SUPPLIED ENCLOSURE, THE METER CUT-OUT AND PEM MOUNTING STUDS MAY ALREADY EXIST IN THE ENCLOSURE.







FIGURE #2
BEZEL INSTALLATION FOR TYPE 3R, 4, & 12 ENCLOSURES
(REFER TO NOTE 2)



DETAIL 'A'
 DIGITAL POWER METER MOUNTING
 FOR TYPE 1, 3R, 4, & 12 ENCLOSURES

DETAIL 'B'
 BEZEL MOUNTING FOR TYPE 3R, 4, & 12 ENCLOSURES



KEEP 2" AROUND THE PRODUCT CLEAR OF ANY OBJECT FOR PROPER INSTALLATION




FIGURE #3
 CUT-OUT DIMENSIONS FOR DIGITAL POWER METER
 (REFER TO NOTE 3)

FIGURE #4
 DIGITAL POWER METER DIMENSIONS

INDEX

A

ac power supply, 2-2
accessory 72E, 2-3
accuracy, 1-3
active power, 4-1
address, 3-7, 3-8
apparent power, 4-1
arrow keys, 3-1
ASCOBUS II, 3-7, 3-8
ATS position, 2-2, 4-1
auxiliary contact, 2-2
average current & voltage, 4-1

B

Backlight time selection, 3-16
baud rate, 3-7, 3-8
buttons (arrows, enter, escape), 3-1

C

cable, communication, 2-3
change password, 3-3
clear energies, 3-13
Clear Demand, 3-18
Clear Run-Time counter, 3-11
Clear Min Max parameters, 3-12
clock (real time) setting
 Date (mm, dd, yy), 3-22, 3-23
 Day (of the week), 3-24
 Time (hh, mm, ss), 3-20, 3-21
Communication, 3-2, 3-7, 3-8
connections, 2-1, appendix 1
Connectivity Module, 2-3
Contrast selection, 3-17
control overview, 3-1
current, 1-4, 4-1
CT current transformers,
 2-2, 3-6, 3-14, appendix 1
DANGER statement, 2-1, 2-2

D

DANGER statements, cover, 2-1
Date (mm, dd, yy), 3-22, 3-23
Date Format (US, EU, ISO), 3-21
Day (of the week), 3-24
Demand, clear, 3-18
Demand Intrl (Interval), 3-19
device ratings, 1-4
display, 4-1, 4-2, 4-3
Display, 3-2, 3-15, 3-16, 3-17

E

electrical system type,
 3-4, appendix 1

engine runtime counter, 3-9, 3-11
emergency source, 3-5
energy registers, 3-13
enter key, escape key, 3-1

F

Feature 14A, 2-2
frequency, 1-3, 1-4, 4-1

G

General settings, 3-3
 Clear Demand, 3-18
 CT Ratio, 3-6
 CT-N Ratio, 3-6
 Date (mm, dd, yy), 3-22, 3-23
 Day (of the week), 3-24
 Demand Intrl (interval), 3-19
 PT Ratio, 3-6
 System Type, 3-4
 Time (hh, mm, ss), 3-20, 3-21
general information, 1-1
ground connection, 2-2

H

HELP 800-800-2726(ASCO)
 customer@asco.com

I

initial setup, 3-1
inputs, 1-4, appendix 1
installation, 2-1, appendix 2
interval, demand, 3-19

J

J1 (RS-485), J2 (serial), 2-3
J3, transfer switch position, 2-2
J6, dc power supply, 2-2
JP1 jumper, appendix 1-6

K

kW, kVA, kVAR, 1-2, 3-1, 4-1, 4-2

L

Language selection, 3-15
load source to monitor, 3-5

M

measurements, 1-1, 1-2, 1-3
Modbus RTU, 3-7
mounting, 1-4, 2-1, appendix 2

N

net power, 4-1
neutral current, 4-1

normal source, 3-5

O

operation, 4-1
other source to monitor, 3-5
overview, 3-1
overview screen, 3-4, 4-1, 4-2

P

parameters, 1-3
password selection, 3-3
ports, 3-7, 3-8
power, power factor, 4-1
power supply, 1-4, 2-2, appendix 1
protocol, 2-3, 3-7, 3-8
PT potential transformer,
 3-6, Appendix 1

R

ratings, 1-4
RS-485, 3-8, appendix 1

S

SCI serial communication interface,
 3-7, 3-8
Settings, 3-2
 General, 3-3
 Communication, 3-7, 3-8
 Display, 3-15
setup, initial, 3-1
Source (to monitor), 2-2, 3-5
specifications, measurement, 1-3
System Type, 3-1, 3-4

T

temperature, 1-4
Time (hh, mm, ss), 3-20, 3-21
total harmonic distortion THD, 4-2
transfer switch, 2-2, 3-5, 3-10
TTL interface, appendix 1

U

unbalance current & voltage, 4-1

V

voltage, 1-3, 4-1
voltage connection, 2-2, appendix 1

W

Watts, 1-2, 1-3
wiring diagrams, appendix 1